


Переходники

Материал: латунь

N


Номер	Rp1	Rp2	L	I	SW	Серия
N6-18	UNEF 7/16"-32	1/8" BSP	13	8	13	N6
N9-14	UNEF 5/8"-24	1/4" BSP	18	11	19	N9


Штуцеры под шланги

Материал: латунь

N / 500


Номер	Rp	d1	d	L	L1	SW	Серия
N6-6M	UNEF 7/16"-32	5	6	32	27	11	N6
N6-9M	UNEF 7/16"-32	6	9	32	27	11	N6
N9-11M	UNEF 5/8"-24	9	11	33	27	16	N9
N9-13M	UNEF 5/8"-24	9	13	33	27	16	N9
500-19M	BSP 1/2"-14	16	19	56	46	22	N16


Уголки 90°

Материал: латунь

N / 500

Номер	Rp1	Rp2	R	SW	Серия
N6-90	UNEF 7/16"-32	UNEF 7/16"-32	-	15	N6
N9-90	UNEF 5/8"-24	UNEF 5/8"-24	-	21	N9
500-90	-	1/2" NPT	1/2" BSPT	26	N16


Уголки 45°

Материал: латунь

N / 500

Номер	Rp1	Rp2	SW	Серия
N6-45	UNEF 7/16"-32	UNEF 7/16"-32	15	N6
N9-45	UNEF 5/8"-24	UNEF 5/8"-24	21	N9
500-45	1/2" NPT	1/2" BSP	26	N16

